产品介绍

WiFi数据采集棒是爱士惟自主研发的智能数 据采集设备,负责采集光伏逆变器工作数据, 并上传云端。

采集棒按照与逆变器的连接方式,分为两种: ① USB 连接插头






产品特性

- 远程固件升级
- 网络诊断
- LED指示
- 即插即用
- 断点续传
- IP65防护

产品指示



蓝色LED:网络通讯指示

绿色LED:逆变器通讯指示

产品标签:产品信息展示

连接插头:连接到逆变器

注:LED只有在采集棒上电工作后才会点亮显示。

包装清单

编号	名称	数量
1	WiFi数据采集棒	1
2	使用手册	1

安装说明

首先逆时针拧掉逆变器上对应的防尘帽。



插入数据采集棒,再沿顺时针方向拧紧浮动螺 母,如下图所示。





拆卸数据采集棒时,请按下图所示逆时针旋 转浮动螺母,数据采集棒取下后请锁上防尘 帽,保证逆变器防护。





注意:安装或拆卸数据采集棒 时,请勿握住采集棒本体旋转,



注:安装逆变器时,请尽量靠近路由器20m以 内,以保证信号良好。

WiFi-Stick

User Manual

使用手册


WiFi数据采集棒

Product Introduction

WiFi-Stick is a wireless communication module developed by AiSWEI. It will collect the operating data of the inverters and upload the data to the cloud.

According to the connection with the inverter, there are two types of WiFi-Stick:


- ① USB
- 2 4pin connector



Product features

- Remote firmware update
- Network diagnosis
- LED indicators
- Plug-in connector
- Automatic resumption of data transmission once network recovering
- IP65 Protection Class

Product Manual



Blue LED: Indicator for network communication

Green LED: Indicator for inverter communication

Type label: Product information

Connector: Connection to the inverter

Note: LED will only start working after power on.

Delivery List

No.	Name	Quatity
1	WiFi-Stick	1
2	User Manual	1

Installation Guide

Please remove the anti-dust cap of the connector on the inverter by rotating anti-clockwise.



Insert the WiFi-Stick to the connector on the inverter. Rotate the nut on the WiFi-Stick clockwise and tighten it, as shown in the figure on the right.



When removing the WiFi-Stick from the inverter, please unscrew the nut anti-clockwise as shown in the figure below. After removing, please reattach the anti-dust cap on the inverter connector to ensure protection class.







Caution: Please do not rotate the WiFi-Stick main body during installation.



Note: Install the inverter within 20m of the router to ensure good signal.

电站监控

App下载

用户可通过扫描如下一维码下载安装AiSWFI App,然后进行安装。



微信公众号

关注微信服务公众号获取更多服务。



配置网络

连接数据采集棒到逆变器,上电开机。 查看绿色LED灯在快闪模式(WiFi一键配网模式)。

此时打开手机App,点击App首页下方的"监控配置", 扫描数据采集棒上的二维码即可开始配置网络。

注:只支持2.4GHz颜段网络。

创建账号及电站

打开AiSWEI App,首页左上方注册账号。注册 完毕登陆之后,点击右上"+"创建电站。具体可 参考App操作说明书。

LED指示及故障排除

绿色LED:逆变器通讯指示

- 绿色LED灯灭:数据采集棒数据采集端硬件故障, 请联系售后。
- 绿色LED灯慢速闪烁:绿色LED灯每10秒闪烁一次, 说明采集棒与逆变器通讯正常。
- 绿色LED灯快速闪烁:采集棒进入一键配网状态. 不采集逆变器数据。

蓝色LED:网络通讯指示

- 蓝色LED灯灭:数据采集棒连接路由器异常,需 检查路由器网络名称和密码是否正确;检查采 集棒探测无线信号强度。
- 蓝色LED灯常亮:设备已经连上云端,可以在云 端建电站查看数据(具体请参考AiSWEI Cloud说 明书)。
- 蓝色LED灯闪烁:设备未连接到云端,如果当前 设备已经连上路由器, 请通过路由器配置界面 查看当前设备是否具有连接外网权限。

AP模式配网:需要连接设备的网络重新写入路由器信息 (AISWFI-XXXX), 密码为设备外壳上注册码。 (配网请参照App使用说明书)。

产品质保

感谢您购买爱士惟科技(上海)有限公司的数据采 集棒,为了更好的为您服务,在购买本产品后,请认 真阅读、填写并妥善保管好此质保卡。

客户埴写内容:

#/ % 7/13			
用户名		联系人	
产品名称		购买日期	
序列号			
联系电话			
用户地址			
订单编号			
维修 记录	日期	故障原因	及处理

保修说明

产品若出现质量问题需要保修时,请将此质保卡与 所购数据采集棒一起妥善寄回本公司售后服务处。

注意事项

- 1. 自您购买本产品签收首日起,凡按照使用手册安装 使用,在质保期内出现非人为质量问题,我们提供 免费维修。
- 2. 非本公司产品质量引起的问题, 如使用不当、 保管不妥、擅自拆机等原因造成的损坏,一律 不在保修范围内。

网址: www.aiswei-tech.com 地址:上海市黄浦区蒙自路757号905B室

服务邮箱: service.china@aiswei-tech.com

爱十惟科技(上海)有限公司

服务热线: 400 801 9996

联系方式

合格证

本产品经检验符合出厂标准

Plant Monitoring App download

Download the AiSWEI App by scanning the QR code below.



Network configuration

Connect the WiFi-Stick to the inverter and turn on the DC-switch of the inverter. The green LED on the WiFi-Stick will blink quickly. The WiFi-Stick is now ready for the network configuration. Open the App and click on the "Monitoring settings" on the main page. Scan the QR code on the WiFi-Stick to enter network configuration mode.

Note: Only support network with 2.4GHz bandwidth.

Account registration and plant creation

Open the AiSWEI App and register a new account. After completing the account registration and logon, click on the "+" icon to create plant. Please refer to the App user manual for further details.

LED indicators and troubleshooting Green LED: Inverter communication indicator

- Green LED turns off: Hardware fault, please contact our service.
- Green LED blinks slowly: Green LED blinks slowly every 10 seconds, the communication between WiFi-Stick and inverter is Ok.
- Green LED blinks quickly: WiFi-Stick enters network configuration mode. Inverter's data collection is disabled.

Blue LED: Network communication indicator

- •Blue LED turns off: Connection to the router fails. Please check if the network SSID and password are correct or the wireless signal
- •Blue LED turns on: The device is now connected to the cloud, you could create a power plant on AiSWEI Cloud to monitor the parameters of the plant. (Please refer to the AiSWEI Cloud user manual for further details).
- •Blue LED blinks: The device is not connected to the cloud. If the device has been connected to the router, please check whether the device has the permission to connect to the internet via the configuration page of the router.
- Note: For AP network configuration work, you need to be connected to the local WLAN network of the device (AISWEI-XXXX) to reenter the router information. The password for the local WLAN network would be the registration key, which could also be found on the type label. (Please refer to the App user manual for further details on network configuration).

Warranty

Thank you for purchasing the WiFi-Stick product from AISWEI Technology (Shanghai) Co., Ltd. Please keep this warranty card carefully. so that you could enjoy our full-service benefits.

Filled in by the customer:

Customer name		Contact person	
Product name		Purchase date	
Serial number			
Contact number			
Address			
Order number			
	Date	Description of issue and measu	
Service information			

Warranty description

Please send the faulty device and warranty card together back to AiSWEI service center. The shipping cost will be covered by the customer.

Note

- 1. From the date on the purchasing invoice, any quality issue which happens within warranty period will be fully covered by the warranty.
- 2. The warranty does not cover damages that occur due to incorrect installation. commission, inappropriate storage and other unreasonable factors.

Contact

Service email: service.EMEA@solplanet.net

APAC

Service email: service.APAC@solplanet.net

Service email: service.LATAM@solplanet.net

Aiswei Greater China

Service email: service.china@aiswei-tech.com Hotline: +86 400 801 9996

Service email: service.taiwan@aiswei-tech.com Hotline: +886 809089212

https://solplanet.net/contact-us/

Oualification Certification

This product has passed the factory quality check control